

## ListenTALK Quick Start Guide

• LKR-12



## INTRODUCTION

### Thank you for purchasing ListenTALK!

For additional details on use, adjustment, or programming, download the full ListenTALK Operations Manual from [www.listentech.com/support/manuals](http://www.listentech.com/support/manuals). To purchase headphones and other accessories, visit: [www.listentech.com/shop-listen](http://www.listentech.com/shop-listen).

### Charge ListenTALKs

Remove the protective screen cover and clear plastic battery isolation tab. Fully charge by connecting Micro USB to USB charger or charge in the optional Docking Station. Status LED will flash and then be lit solid when fully charged. Optionally, insert three AAA alkaline batteries into Receiver equipped with the Alkaline Battery Case.

### Power On

Press and hold Power Button to turn on. Press and hold three seconds to turn off. Green LED will flash and then be lit solid green when device is on and paired to a group leader. Green LED will continue flashing if receiver is not paired to a group or the leader is not turned on.

While unit is on, momentarily press Power Button to activate the LED Status. If the unit is paired the status LED will flash green once followed by the white LED flashing the battery status: 1 = 1/4, 2 = 1/2, 3 = 3/4 and 4 = Full.



For more information visit  
[www.listentech.com](http://www.listentech.com)

## **Create a Group**

To create a group, designate a leader unit by inserting a red leader clip on any ListenTALK LK-1 Transceiver unit. Place Transceiver into red Leader pocket on Docking Station Tray. Place Receiver in any participant pocket of Docking Station Tray and momentarily push pair button on front of tray. Green LED will flash 3 times upon a successful pairing.

Note: LKR-12 Receivers can only be paired to a group using a Docking Station.

## **Connect Headphones**

Connect Listen Technologies headphones or use standard smartphone earphones.

### **Volume**

Press Volume Up or Volume Down button to control volume.

## **Programming and ListenTALK Software Suite**

The ListenTALK Software Suite, available at [www.listentech.com/support/software/](http://www.listentech.com/support/software/), features complete setup, inventory management, group creation and naming. Please refer to the ListenTALK Operations Manual.

## **Hearing Safety**

This product amplifies audio to a high level which could cause hearing damage. To protect your hearing, turn down the volume before putting on the Ear Speaker or Headphones, then adjust to your preference.

### **Medical Device Safety**

Before using this product with an implantable or other medical device consult with your physician or the device manufacturer. Always confirm you are using this product in accordance with safety guidelines established by your physician or the manufacturer.

## **Recycling**

Please help us protect the environment by properly disposing of batteries. Take batteries or equipment to any electronic recycling collection point or return them to the factory.

© 2018 Listen Technologies Corporation®  
All Rights Reserved 2018

Visit Listen at [www.listentech.com](http://www.listentech.com)  
or telephone +1.801.233.8992 or  
1.800.330.0891

20180516